# Neat Pad Controller zoom neat. Guide





# Neat Pad Controller Guide

## Table of Contents

1. How to Start a Meeting

a. How to Start an Instant Meeting

b. How to Start a Scheduled Meeting

2. How to Join a Meeting

- a. Upcoming Alert for a Scheduled Meeting b. Joining from Neat Pad
- 3. Screen Sharing
  - a. One-Click Direct Share
  - b. Share with a Key
  - c. Desktop Sharing in a Zoom Meeting
- 4. Neat Pad In-Meeting Controls
- 5. Camera Controls
  - a. Option 1: Auto-Framing
  - b. Option 2: Auto-Framing with Multi-Focus Framing (Neat Symmetry)
  - c. Option 3: Multi-Stream

#### d. Option 4: Manual

#### 6. Managing the Meeting

a. How to Manage Participants and Change Hosts b. How to Reclaim the Host Role



How to Start a

neat.

Neeting


## How to Start an Instant Meeting

1. Select **Home** from the left side of Neat Pad.

2. Select New Meeting.

3. Select Manage Participants to invite

#### others by contacts, email or SIP.





How to Start a

neat.


# Meeting

## How to Start a Scheduled Meeting

1. Select **Home** from the left side of Neat Pad.

2. Press the meeting which you would like to start.

#### 3. Press Start on the screen.






# How to Join a Neeting

## **Joining from the Upcoming Meeting Alert**

1. You will receive an automatic meeting alert a few minutes ahead of your meeting start time.

#### 2. Click Start when you are ready to begin your meeting.






# HOW to Join a Neeting

## **Joining from Neat Pad**

- 1. Select **Join** on the menu.
- 2. Enter your **Zoom Meeting ID** (which you
  - will find in your meeting invite).
- 3. Press **Join** on the screen.
  - a. If the meeting has a **Meeting**

## Passcode, a pop-up window will appear. Enter the **Meeting Passcode** and press **OK**.






# HOW to Screen


# Share


## **One-Click Direct Share**

- 1. Open your Zoom desktop app
- 2. Click on the Home button on the top left.
- 3. Press the Share Screen button & you will directly share with your desktop on your









Call a Room

View today's upcoming meetings (1)

#### Learn more at support.neat.no

.



Start

•••

How to

neat.

Screen

# Share

## Sharing with a Key


Sharing <u>outside</u> of a Zoom meeting:

- 1. Select Share Screen from the menu.
- 2. Press **Desktop** on your screen & a pop-up


with the sharing key will appear.

3. Tap Share Screen on Zoom app, a Share

## Screen pop-up will appear. 4. Enter the **Sharing Key** & press **Share**.



2:23 PM	Tuesday, Mar 1	
<b>Test Meeting</b> 1:45 PM - 2:45	Share Screen	
Host: Jessi 2	Share from	
	Desktop	
		+
		Join Share Screen





# How to Screen

# Share

## Sharing with a Key

Sharing <u>within</u> a Zoom meeting:

1. Press **Share Content** in your in-meeting menu & a pop-up with the sharing key will

appear.

2. Tap Share Screen on Zoom app, a Share


## Screen pop-up will appear. 3. Enter the **Sharing Key** & press **Share**.






# Desktop Sharing

## **Desktop Sharing in a Zoom Meeting**









**Camera Options:** Manual, Auto-framing, & Smart Gallery

End Meeting for All or Leave






Camera Controls

neat.

How to Maneuver Between the Various Camera Control Options 1. During your meeting you can bring up the local camera control menu and choose from four camera options.

## 2. To do so, simply press **Camera Control** in your in-meeting menu.










## **Option 1: Auto-Framing**

**Auto-Framing** allows everyone in the meeting to be framed at any given time. The camera seamlessly adjusts automatically to keep you in the view.



Three participants framed together in group Auto-Framing.






# Camera Controls

## **Option 2: Auto-Framing with Multi-Focus** Framing (Neat Symmetry) **Neat Symmetry** takes Auto-Framing to the next level.

When there are meeting participants in a room, Neat Symmetry zooms in on people at the back and shows them in equal proportion to participants at the front. Furthermore, Neat Symmetry allows the camera to automatically follow each framed-participant as they move around.















#### **Option 3: Multi-Stream**

If there are two or more participants in the meeting room, the Multi-

**Stream** feature provides a new experience for the remote participants in the meeting room.









## **Option 3: Multi-Stream (Continued)**

The meeting room is split over three separate frames:

the first frame provides full view of the meeting room;

Camera Controls

the second and third frames show individually framed views of the participants in the meeting room (e.g. with four people, two in each frame; with six people, three in each frame).



Multi-Stream with six participants, viewed over three frames in Gallery View.



Multi-Stream with three participants in the meeting room, viewed over three frames in Gallery View.






# Camera Controls

### **Option 4: Manual**

**Preset** allows you to adjust the camera to the desired position.

1. Hold the **Preset 1** button down until you see a pop-up. Enter system passcode (the system passcode is found under system settings on your Zoom admin portal).

2. Adjust camera & select Save Position.










### **Option 4: Manual (Continued)**

- 3. Hold the **Preset 1** button again, select **Rename** and give
  - your preset a name. Here, we chose the preset name: **best**.
- 4. You can take the same action for **Preset 2** & **Preset 3**.





# Managing the

## How to Manage Participants and Change Hosts

1. Press Manage Participants in your inmeeting menu.

2. Find the participant you want to assign the host rights to (or make other

# Meeting

# changes to) & tap on their name.


3. Select Make Host from the drop down

list.

Manage Participants

2

Parti	Participants (2)	
S Spacelab (Host, me)	Chat	D1 Q
	Stop Video	
Kristina Zumfeld	Pin Video	
	Request Camera Control	
	Allow Recording	
	Make Host	





# Managing the

## How to Reclaim the Host Role

1. Press **Manage Participants** in your inmeeting menu.

2. You will see the **Claim Host** option in the lower section of the participant


# Meeting

#### window. Hit Claim Host.

Manage Participants

2







# Managing the

# How to Reclaim the Host Role (Continued)

3. You will be asked to enter your **Host Key**. Your host key is found on your *Profile page* under the Meeting section within your

# Meeting

#### Zoom account on **Zoom.us**.

